



WATER  
LEVEL


**GROUND LEVEL RESERVOIR**



**ELEVATED RESERVOIR**

As noted in the schematic, Figure 1, the WATER LEVEL FLOAT ASSEMBLY, Figure 3, must be positioned at an elevation such that the float valve itself is approximately 2" below the water level in the reservoir.

The FLOAT VALVE, shown in the photo below, has a provision for minor adjustments of the water level. An example of a suction line FILTER is also included in the photo.



**Plant & Garden Accessories**

(602)-971-8110 Fax: (602)-971-0212

<http://www.greengoddess.com>

4139 E. Bell Rd., Phoenix, AZ. 85032