

BACK WASHING FOUNTAINS



Step 1.) Turn pump off. Hook garden hose up to hose bib.



Step 2.) Open up hose bib



Step 3.) Turn ball valve after hose bib off. Turn pump on and empty fountain. When pump starts sucking air turn pump off and open ball valve and close hose bib and remove garden hose. Refill fountain then turn pump back on.